

User Guide

Thank you for purchasing a SKOPE refrigeration product.

Safety

Always observe safety precautions when using any electrical appliance. Read these instructions carefully and retain them for future reference.


WARNING

- Ensure the appliance is disconnected from the power supply before performing any cleaning or maintenance.
  - Do not cover the grilles or block the entry or exhaust of airflow by placing objects up against the refrigeration unit.
  - Should manual defrosting be necessary, turn off the refrigeration system and allow the ice to melt by air circulation. Collect ice and water during defrost to prevent a slip hazard. Do not use mechanical methods to remove ice, as this may damage the refrigeration circuit.
  - Do not use any electrical devices or appliances inside the food storage compartment.
- 
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
  - Do **not** use this appliance for other than its intended use.
  - Do not insert fingers/foreign objects into any holes.
  - Only use this appliance with the voltage specified on the cabinet rating label.
  - Ensure the appliance has adequate ventilation as this is essential to economical, high performance.
  - Be careful not to touch moving parts and hot surfaces.
  - For your own safety and that of others, ensure that all electrical work is done by authorised personnel.
  - If the power supply flexible cord becomes damaged, it must be replaced by an authorised service agent or similarly qualified person in order to avoid a hazard.
  - Ensure all necessary safety precautions are observed during installation or removal of the refrigeration unit.
  - The appliance is not designed to be stable while in motion. Use extreme caution when moving or transporting it.
  - Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
  - Do not exceed a maximum load of 20 kg per shelf.
  - If the cabinet is to be scrapped, ensure the cabinet is unplugged from the power supply and cut off the mains flex close to the back of the cabinet. Be mindful of the risk of animals or children becoming trapped in the appliance – either remove or secure doors if necessary.
  - Refrigerant must be removed by a qualified service person and the cabinet recycled/disposed of in accordance with local regulations.
  - When moving a vertical cabinet, always:
    - Use at least **two** people, as cabinets are heavy and may tip over. This could cause injury to a person, or damage to the cabinet which requires repair or replacement.
    - Move the cabinet slowly, and with care.

This cabinet is designed to operate within a specific climatic class environment. See the cabinet rating label inside the cabinet for climate class number.

Climate class	Ambient temperature	Relative humidity
3	25°C	60%
4	30°C	55%
5	40°C	40%
7 (tropical)	35°C	75%

The cabinet includes relevant hazard symbols that may be associated with the cooler. Refer to the information below for symbol description.



**WARNING**

The refrigeration system contains flammable R290 refrigerant. Do not tamper with it. The refrigeration system must only be serviced by qualified personnel.


Service and Support

We know you will get years of satisfaction from your new SKOPE product when you follow a few simple preventative maintenance guidelines.  
Helpful information is available on the SKOPE website: [www.skope.com/serviceandsupport](http://www.skope.com/serviceandsupport)




Installation Guidelines

Ensure you consider and meet the installation guidelines below.




Ventilation

Ensure all ventilation requirements below are met.




Surface

The installation surface must be capable of supporting the loaded cabinet.





Door/Drawer Opening

Allow adequate space for the door/s and/or drawer/s to open and close properly.




Climate Class

The cabinet must be installed in an environment within its climate class which is stated on the cabinet rating label inside the cabinet, and explained on the front page of this user guide.




Sunlight

Do not install the cabinet in direct sunlight.




Uneven Surface

Do not install the cabinet on an uneven surface.



Power Supply

Do not overload the power supply.




Blocking Ventilation

Do not store boxes or items in front or on top of the cabinet.

Ventilation Requirements


This cabinet must have the following ventilation clearances at all times:

Upright Cabinets




Underbench Fridges

No above clearance required




Underbench Freezers

No above clearance required




Chef Base Cabinets



\*When installed for continuous duty in climate class 7 environment (35°C ambient/75% relative humidity), SKOPE recommends providing 50 mm clearance around the sides and back of the cabinet.


Shelves

Each shelf is held in place with shelf rails, which clip into the shelf support strips. You can adjust the height of the shelf rails. The shelf rails are suitable for use with Gastronorm pans.




## Drawers

Where fitted, remove drawers for cleaning. Pull the drawer out of the cabinet, release the latches at the side of drawer as shown, and lift the drawer out at an angle. You can also remove the drawer slider by releasing the side catches as shown. Reverse the operation to refit the drawers to the cabinet after cleaning.



## Loading Product

Let the cabinet cool down to the desired storage temperature before loading it with product. When loading the shelves:



### Internal Airflow

Leave 25 mm space between product and the back and top of cabinet interior.



### Maximum Loading

Do not overload the shelves.



### Shelf Flexing

Remove product if the shelf is flexing.



### Shelf Overhang

Do not let product overhang the shelves.



### Cabinet Floor

Do not load product on the cabinet floor. Use the shelves.

## Door Lock/s

The cabinet is fitted with key locks, which can be operated with the supplied key.

## Electronic Controller

The electronic controller regulates the cabinet internal temperature, signals alarms and captures operational information. The internal temperature is factory-set for storage of perishable product.

To customise the settings to your requirements and view historical data, download the SKOPE-connect app from the Google Play Store or Apple App Store, and connect via Bluetooth wireless technology.



## Lights

The interior lights switch on and off automatically depending on use.

## ChefBase – Weight Limits

To ensure a safe workplace, carefully examine and make note of how much weight you plan to place on the bench top of the ChefBase fridge. SKOPE recommends no greater than 200 kg for the 2-drawer fridge and no greater than 400 kg for the 4-drawer fridge.

## ChefBase – Marine Edge

A marine edge on top of a ChefBase helps contain drips and spills. It also discourages items and equipment from slipping off the top, which increases safety.

## ChefBase – Heat Shield

A heat shield is fitted inside the bench top of ChefBase cabinets which can deflect some of the cooking equipment heat away from the refrigerated space. It is important to follow the equipment manufacturer's guidelines to maintain food-safe holding temperatures and prolong the refrigeration unit's life.

## Cleaning Before First Use

The cabinet interior and food contact surfaces such as the worktop must be thoroughly cleaned and sanitised before first use. Ensure the cabinet is unplugged from the power supply before cleaning, and use only standard stainless steel cleaners suitable for food preparation areas. If required, the cabinet exterior can be cleaned as instructed on the back page of this user guide.



Apple App store



Google Play store

## Routine Cleaning

Ensure the cabinet is unplugged from the power supply before cleaning.

**IMPORTANT:** Do **not** use abrasive, corrosive or solvent-based cleaners, as they could damage the protective coating on the door or drawer.

Wipe the outside of the cabinet with a damp cloth, and the inside of the cabinet with standard stainless steel cleaners suitable for food preparation areas. Take care to keep moisture away from electrical parts.

The condenser coil must be kept clean. SKOPE strongly recommends cleaning the condenser coil and air filter monthly. Do **not** use hard or sharp tools to clean the coil as these may cause damage.

### Vertical cabinets


#### Clean the air filter

1. Unplug the cabinet from the mains power.

2. Remove the filter, which is located on the side of the condenser coil, on top of the cabinet by reaching over the top of the cabinet and sliding the filter up and off.

4. Clean the filter with a vacuum cleaner, wash with cold water, and shake off any excess water before refitting.

- Do **not** apply hot water, blow-dry, or place in a dishwasher.
- If necessary, discard and refit a new filter.




#### Clean the condenser coil


1. Unplug the cabinet from the mains power.

2. Remove the air filter (see above).

4. Brush the condenser coil with a soft brush to remove any dust and fluff.



6. Refit the front panel and reconnect the cabinet to the power supply.



#### IMPORTANT

When refitting, ensure the tabs on the back of the sign are located in the notches on top of the cabinet, and that the sign is pushed fully in and secure.

### Underbench cabinets


#### Clean the air filter

1. Unplug the cabinet from the mains power.

3. Remove the filter, which is located behind the unit bottom grille by rotating the grille out and sliding the filter up and off.

5. Clean the filter with a vacuum cleaner, wash with cold water, and shake off any excess water before refitting.

- Do **not** apply hot water, blow-dry, or place in the dishwasher.
- If necessary discard and fit a new filter.




#### Clean the condenser coil

1. Unplug the cabinet from the mains power.

3. Remove the air filter (see the previous procedure).

5. Brush the condenser coil with a soft brush to remove any dust and fluff.

7. Refit the filter, close the bottom grille, and reconnect the cabinet to the mains power.



## Defrosting (freezer only)

To ensure efficient operation, defrost the cabinet when ice and frost has built up 20 to 30 mm inside the cabinet.

#### CAUTION

Do not use mechanical methods (scraping, chiselling) to remove ice, as this may damage the refrigeration circuit. Ensure ice and water is collected during defrost to prevent slip hazard.

#### Defrost the freezer

1. Remove all product from the cabinet and store in a suitable place.

2. Unplug the cabinet from the power supply.

3. Leave the door open and allow the ice to melt. Collect ice and water during the defrost.

4. Once all ice has melted and water is cleaned up, reconnect the cabinet to the power supply. Let the cabinet cool down to the desired storage temperature before reloading product.